Connection



- Control circuit EEx ia IIC
- Lead breakage (LB) monitoring and short-circuit (SC) monitoring
- Analogue output 0/4 mA ... 20 mA
- · 1 serially switched output
- · 1 error message output

24 V DC: KFD2-FSU-Ex1.D

with LC indicator Successor KFD2-UFC-Ex1.D

Function

The frequency current converter converts the input frequency into a set current. It is designed for the connection of a sensor per DIN EN 60947-5-6 (NAMUR), a nonrebounding contact or an electrical switch.

The input frequency (max. 5 kHz), in which 20 mA should flow across the output, is adjustable within the range of 0.001 ... 999 Hz. At higher frequencies, the input frequency should be divided across a pre-separator so that a max. frequency of 1 kHz lies at the microprocessor of the FSU. A load of 0 to 650 Ohm is approved at the analogue output. The present current value is indicated by units with LCdisplays in 3 1/2 characters. The zero point (0 mA or 4 mA) can be adjusted through the "Zero point" potentiometer on the front panel. The zero point is preset at the factory. A readjustment is normally not necessary.

The response time of the analogue output is set using the S5 thumbwheel switch with jumps in the input frequency. The fault signal output, the serial switch output, the power supply and the current output are galvanically isolated per DIN VDE 0160.

The power supply and the current output are galvanically isolated from each other in accordance with DIN VDE 0160.



Composition



033923_ENG.xml 1/22/04

Subject to reasonable modifications due to technical advances

Copyright Pepperl+Fuchs, Printed in Germany Pepperl+Fuchs Group • Tel.: Germany +49 621 776-0 • USA +1 330 4253555 • Singapore +65 67799091 • Internet http://www.pepperl-fuchs.com

1

Technical data

KFD2-FSU-Ex1.D

Supply	
Connection	terminals 17+, 18-
Rated voltage	20 35 V DC
Bipple	< 10 %
Bated current	< 1/9 mÅ
Connection	terminale 1. 0. 0
Connection	
	acc. to IEC 60947-5-6 (NAMOR, DIN 19234), see system description for electrical data
Open circuit voltage/Short-circuit current	approx. 8 V DC / approx. 8 mA
Switching point/Switching hysteresis	1,2 2,1 mA / approx. 0,2 mA
Pulse/Pause ratio	\geq 0,1 ms / \geq 0,1 ms
Lead monitoring	breakage I = 0,05 0,15 mA , short-circuit 6,2 7,4 mA
Output	
Connection	output I: terminals 7+, 8- ; output II: terminals 9+, 13- ; output III: terminals 14+, 15-
Output I	fault signal ; electronic output, passive
Output I and II	
Signal level	1-signal: (L+) -2.5 V (100 mA, short-circuit proof) 0-signal: blocked output (off-state current \leq 10 μ A)
Output II	serial switching ; electronic output, passive
Output III	Analogue output
Current range	0 20 mA or 4 20 mA , max. 25 mA
Open loop voltage	≤ 27 V DC
Load	≤ 650 Ohm
Transfer characteristics	
Resolution	12 Bit (equivalent to 6.1 uA)
Deviation	current-frequncy converter, analogue output: ± 0.6 % of nominal output current $\pm 60 \mu$ A LC display (optional): ± 0.6 % of nominal output current $\pm 100 \mu$ A
Switching frequency	S kHz
Electrical isolation	
	safe electrical isolation acc. to EN 50020
	safe electrical isolation acc. to EN 50020
	available
Electromagnetic compatibility	standards
Directive 89/336/EC	on request
Standard conformity	
Insulation coordination	acc. to DIN EN 50178
Electrical isolation	acc. to DIN EN 50178
Climatic conditions	acc. to DIN IEC 721
Input	acc. to IEC 60947-5-6 (NAMUR, DIN 19234), see system description for electrical data
Ambient conditions	
Ambient temperature	-25 65 °C (248 338 K)
Mechanical specifications	
Protection degree	IP20
Mass	approx. 260 g
Data for application in conjunction with hazardous areas	
EC-Type Examination Certificate	PTB No. Ex-89.C.2145 ; for additional certificates refer to the approval list
Group, category, type of protection	[EEx ia] IIC resp. [EEx ia] IIB
Voltage U ₀	12,7 V
Current Lo	17.3 mA
Power P-	55 mW
Comple	
Supply	
Sarety maximum voltage Um	
Type of protection [EEx ia]	
Explosion group	IIB IIC
External capacitance	1,1 μF 0,45 μF
External inductance	5 mH 2 mH
Type of protection [EEx ib]	
Explosion group	IIB IIC
External capacitance	5 μF 1,2 μF
External inductance	410 mH 114 mH
Outputs	

11/22/04

033923_ENG.xml

Subject to reasonable modifications due to technical advances. Pepperl+Fuchs Group • Tel.: Germany +49 621 776-0 • USA +1 330 4253555 • Singapore +65 67799091 • Internet http://www.pepperl-fuchs.com

Copyright Pepperl+Fuchs, Printed in Germany

Technical data

Safety maximum voltageU _m	40 V DC
Electrical isolation	
Input/Output	safe electrical isolation acc. to EN 50020
Input/power supply	safe electrical isolation acc. to EN 50020
Directive conformity	standards
Directive 94/9 EC	on request
Safety parameter	
CSA control drawing	LR 36087-30
Connection	terminals 1, 3; 2, 3; 4, 6; 5, 6
Input I	
Safety parameter	12,6 V / 650 Ohm
Voltage V _{OC}	12,6 V
Current I _{SC}	19,8 mA
Explosion group	A&B C&E D, F&G
Max. external capacitance C_a	1,273 μF 3,82 μF 10,18 μF
Max. external inductance La	84,88 mH 298,7 mH 744,4 mH

Notes

Lead breakage and short circuit monitoring

The outputs are cut off, when the current in the control circuit is J < 0,1 mA (in respect to lead breakage monitoring) or J > 6 mA (in respect to short circuit monitoring), in this case the fault signal output is switched and indicates a fault through the illumination of LED 2 (red).

Adjustment instructions pre-scaler (S6)

The input frequency f_E can be reduced via a pre-scaler, as the microprocessor of the frequency current converter can process a maximum of 1 kHz (pulse to no-current ratio 1 : 1).

The adjustment is accomplished via a multi position switch.			
Switch in pos. I:	1 : 1 (1 kHz)	Æ	Separator ratio TV = 1
Switch in pos. II:	2 : 1 (2 kHz)	Æ	Separator ratio TV = 0.5
Switch in pos. III:	10 : 1 (5 kHz)	Æ	Separator ratio TV = 0.1
Switch in pos. IV:	100 : 1 (5 kHz)	Æ	Separator ratio TV = 0.01

By means of the solder bridge 1 can be determined, if the serially switched output is operated dependent or independent of the adjustment of the pre-scaler.

Solder bridge 1 in pos. I:	Serially switched output switches pre-scaler independent
Solder bridge 1 in Pos. II:	Serially switched output switches pre-scaler dependent
Delivery:	Solder bridge 1 in position II

Adjustment of the jumper 1

After removal of the cover and of the left-hand side part the jumper is visible on the printed circuit board.



Copyright Pepperl+Fuchs, Printed in Germany

Input frequency adjustment f_F

By means of the thumbwheel switch S1 - S4 the frequency is adjustable, at which the maximum current of 20 mA is to flow. However the position of the pre-scaler should be considered.

Adjustment of the thumbwheel switches

Nominal frequency f _n = (S1 x 100 + S2 x 10 + S3 x 1) x S4 x TV TV = separator ratio	example:	nominal frequency output current adjustment →	0 Hz 3.57 Hz 4 mA 20 mA S1 : 3/S2 : 5 S3 : 7/S4 : 6 (357 x 10 ⁻² Hz) S6 : 1 (T)(= 1)
			S6:I(IV = 1)

Switch S1	(0 - 9) x 100
Switch S2	(0 - 9) x 10
Switch S3	(0 - 9) x 1
Switch S4	according to the table

Switch S4 switch position	Input frequency f _E (S1 + S2 + S3)	0-Point of the output characteristic
0	x 10-0 Hz	0 mA
1	x 10-1 Hz	0 mA
2	x 10-2 Hz	0 mA
3	x 10-3 Hz	0 mA
4	x 10-0 Hz	4 mA
5	x 10-1 Hz	4 mA
6	x 10-2 Hz	4 mA
7	x 10-3 Hz	4 mA

Adjustment of the time response

By means of the thumbwheel switch S5 the time can be set, after which the output current rises in case of an erratic rise of the input frequency.

The value of the time constant t is calculated from the following formula:

$$\tau = \begin{array}{c} 2^{N+1} \\ \hline f_{s} = \text{reference frequency} \\ f_{s} \end{array}$$

The value N can be set at the thumbwheel switch S5 from 0 ... 9.

Step response

