# Multiturn absolute encoder



## PVM58X





# **Technical data**

#### Industrial standard housing Ø58 mm

- PROFIBUS interface
- 30 Bit multiturn
- Ex approval for zone 2 and zone 22
- Speed transfer
- Extended scaling functions
- Programmable limit switches
- Commissioning mode

### **Product description**

This series of PROFIBUS rotary encoders is based on the modern fast technology of singleturn sampling and the mechanical gear box of the multiturn unit. The absolute encoder corresponds to the PROFIBUS profile for encoders, order no. 3.062. Operation is supported based on Class 1 and Class 2.

For operation based on Class 1, position data and diagnostic data bytes 1 ... 16 are available. In addition, the direction of the code can be selected as either cw ascending (clockwise rotation, code course ascending) or cw descending (clockwise rotation, code course descending).

If the rotary encoder is operated according to Class 2, additional functions to those from Class 1 are available. These include scaling of the resolution per revolution and the overall resolution, as well as the preset function. In addition, expanded diagnostic reporting is supported.

Besides, the rotary encoder offers extended functionalities such as speed transfer, extended scaling functions, programmable limit switches and a commissioning mode.

The removable connecting hood contains a slide switch for setting the terminating resistor and the rotary switches for setting the address. Assign a fixed address and bus termination to the encoder with this switches.

The device is designed for shaft mounting and is available in servo flange or clamping flange design. This Profibus encoder is designed for operation in zone 2 and zone 22.

General specifications Detection type		photoelectric sampling
Functional safety related parameters		Prince of the second seco
MTTF <sub>d</sub>		70 a
Mission Time (T <sub>M</sub> )		20 a
L <sub>10h</sub>		1.9 E+11 at 6000 rpm and 20/40 N axial/radial shaft load
Diagnostic Coverage (DC	<u>۱</u>	
Electrical specificatio	,	0 /8
Operating voltage	U <sub>B</sub>	10 30 V DC
	OB	
Current consumption Linearity		max. 230 mA at 10 V DC, max. 100 mA at 24 V DC ± 2 LSB at 16 Bit, ± 1 LSB at 13 Bit, ± 0,5 LSB at 12 Bit
Output code		
Code course (counting di	raction)	binary code programmable,
Code course (counting di	rection)	cw ascending (clockwise rotation, code course ascending) cw descending (clockwise rotation, code course descending)
Interface		
Interface type		PROFIBUS
Resolution		
Single turn		up to 16 Bit
Multiturn		14 Bit
Overall resolution		up to 30 Bit
Transfer rate		0.0096 12 MBit/s
Standard conformity		PNO profile 3.062, RS 485
Connection		
Terminal compartment		in removable housing cover
Standard conformity		
Protection degree		DIN EN 60529, shaft side: IP64 (without shaft seal)/IP66 (with shaft seal) housing side: IP65
Climatic testing		DIN EN 60068-2-3, no moisture condensation
Emitted interference		EN 61000-6-4:2007
Noise immunity		EN 61000-6-2:2005
Shock resistance		DIN EN 60068-2-27, 100 <i>g</i> , 6 ms
Vibration resistance		DIN EN 60068-2-6, 10 <i>g</i> , 10 2000 Hz
Ambient conditions		
Operating temperature		-30 55 °C (-22 131 °F)
Storage temperature		-30 70 °C (-22 158 °F)
Mechanical specificat	ions	
Material		


1


Copyright Pepperl+Fuchs, Printed in Germany

# **PVM58X**

housing: powder coated aluminium flange: aluminium shaft: stainless steel
approx. 600 g (combination 1)
max. 6000 min <sup>-1</sup>
30 gcm <sup>2</sup>
≤ 3 Ncm (version without shaft seal)
40 N
110 N
<ul> <li>II 3G Ex nA IIB T4 Gc</li> <li>II 3D Ex tc IIIC T120°C Dc IP64</li> </ul>
EN 60079-0:2012, EN 60079-15:2010, EN 60079-31:2009

## Dimensions





#### **Electrical connection**

Date of edition 2013-02-26

Terminal	Explanation
L	Ground connection for power supply
B (left)	Data line B (pair 1), Bus In
A (left)	Data line A (pair 1), Bus In
(-)	0 V
(+)	10 V 30 V
B (right)	Data line B (pair 2), Bus Out
A (right)	Data line A (pair 2), Bus Out


Subject to reasonable modifications due to technical advances.

Copyright Pepperl+Fuchs, Printed in Germany Pepperl+Fuchs Group • Tel.: Germany +49 621 776-0 • USA +1 330 4253555 • Singapore +65 67799091 • Internet http://www.pepperl-fuchs.com

(-)	0 V
(+)	10 V 30 V
	The supply lines only have to be connected once (regardless to which terminal). The outgoing bus is being uncoupled while the terminal resistor is on.

The arrangement of the terminals is shown in the section operating elements.

## Indicating and operating elements



# only be assigned once.



The terminating resistor  ${\sf R}_{\sf T}$  (121  $\Omega)$  can be connected to the circuit by means of the switch:

#### **LED-indicators**

LED red	LED green	
off	off	No voltage supply
on	on	Encoder ready, no configuration data received.
		possible reasons:
		- wrong address adjusted
		- wrong bus wiring
on flashing Parameterising or configuration error. Encoder receives data of inco		Parameterising or configuration error. Encoder receives data of incorrect length or inconsistant
		data.
		possible reason:
		- adjusted encoder resolution exceeds
flashing	on	Encoder ready, no communication with master (i.e. wrong address setting)
on	off	Data timeout (> 40 s). (i.e. data lines interrupted)
off	on	Normal operation, Data Exchange Mode
off	flashing	Installation Mode in Data Exchange Mode.

#### Principle of data transmission

3

6<u>5</u>4 **x10** 


participant X

Rт

last participant


RT

**x1** 



#### Parameter table encoder classes P+F 2.1 and P+F 2.2

Octet number (Byte)	Parameter	Bit number
18	PROFIBUS standard parameters	
9	Direction of rotation	0
	Class 2 functionality	1
	Commissioning Diagnostics	2
	Scaling function	3
	Reserved	4
	Reserved	5
	Activate manufacturer specific parameters (Octet 26)	6
	Reserved	7
10 13	Desired measuring steps (reference: Octet 26, Bit 0 and 1)	
14 17	Overall resolution	
18 25	Reserved	
26	Reference for desired measuring steps	0
		1
	Activate commissioning mode	2
	Reduced diagnosis	3
	Reserved	4
	Activate lower software limit switch	5
	Activate upper software limit switch	6
	Activation of the parameters from Octet 27	7
27 30	Lower limit switch	
31 34	Upper limit switch	
35 38	Physical measuring steps	
39	Reserved	0
	Rotary encoder type (singleturn or multiturn)	1
	Reserved	2
	Reserved	3
	Selection of the unit for speed transfer	4
		5
	Reserved	6
	Reserved	7



5

Copyright Pepperl+Fuchs, Printed in Germany